

IMPORTANT
PLEASE DO NOT RETURN TO STORE
If You're Having Trouble, We're Here to Help!



Call us 24/7 at 1-855-292-4087
E-mail us at support@alteclansing.com or visit us at alteclansing.com

REGISTER YOUR PRODUCT
To receive news, exclusive deals, OTA or
firmware updates, warranty information and
more please register your product at
alteclansingsupport.com



ALTEC LANSING

Follow us
@alteclansingofficial

Follow us
@alteclansing

Follow us
@alteclansingofficial

12 Month Limited Warranty
All Altec Lansing products come with
12 month limited warranty
from the date of its original purchase

24 Hour Customer Support
We love our customers, and we care
about your experience with Altec
Lansing. If you need
assistance, please call us at
1-855-292-4087
or e-mail support@alteclansing.com
www.alteclansing.com

In the Box

IMW1050 HydraOrbit Everythingproof™
Wireless Speaker

USB-C Charging Cable

Strap

A Closer Look

LED Indicator Light

Volume Up/Next Track
Volume Down/Previous Track
Link Button
Power Button/
Answer Calls/Voice Assistant

Reset

Charging Port

Charging

~3-4 Hours
Full Charge

● (red) = Charging
○ (off) = Charging Complete

**Powering On/
Bluetooth
Pairing**

1-2 SEC
PRESS & HOLD

Pairing Mode
Blue Flashing LED

Paired
Solid Blue LED

**Speaker
Controls**

PRESS

Play/Pause
Volume Up
Volume Down
Answer & End Call

PRESS & HOLD (2 sec)

ON/OFF
Next Track
Previous Track
Reject Incoming Call

**True Wireless
Pairing**

Turn on the first speaker and connect it
with a Bluetooth compatible device.

Turn on the second speaker and press the
power button on that speaker.

Press and hold the power button for 2-3
seconds on the first speaker. The first
speaker will now connect to the
second so they both play in sync.
The indicator LEDs will illuminate green.

To end TWSP press & hold the power button on either speaker.

**Voice Assistant
/ Reset**

Press x2

To activate Voice Assistant
(Siri or Google Assistant)
when connected to phone.

Reset: Press & Hold
Volume # & #

Disconnect Bluetooth: Press
and hold for five seconds and
the speaker will beep.
Reset all connections: Press
and hold for ten seconds, and
the speaker will power off. All
pairing information is reset.

Overall battery performance varies dependent upon
use setting, and environmental conditions. For
further information, please visit
www.alteclansing.com

Answering Calls

PRESS

+ Volume Up
- Volume Down
Answer Call/
End Call
PRESS & HOLD
Ignore Call

FOLLOW US ON

#myalteclansing

Changes or modifications not expressly approved by the party responsible
for compliance could void the user's warranty. To identify the recipients, the
device is marked with Part 15 of the FCC Rules. Operation is subject to the
condition that the device does not cause any interference with licensed operations.
This equipment is a Class 1 digital device in accordance with the limits for a
digital device as specified in Part 15 of the FCC Rules. This device has been
designed or modified so that it meets the requirements of the FCC. This device
is not intended for use in aircraft or other restricted environments. However,
this device is not certified for use in aircraft or other restricted environments.
If you experience any interference with your device, please contact the
manufacturer for assistance. The user is responsible for ensuring that the
equipment is used in accordance with the FCC rules and regulations.
- Reconnect or release the receiving antenna and receiver.
- Connect the equipment between the use of the antenna and receiver.
- Consult the dealer or an experienced radio-TV technician for help.
This equipment complies with FCC radiation exposure limits set forth for an
uncontrolled environment.
This transmitter must not be co-located or operating in conjunction with any
other antenna or transmitter.

Sakar International Inc.
301 Center Street
Edison, New Jersey 08817, USA
855-292-4087
www.alteclansing.com