ALTEC LANSING

JUST LISTEN.

Baby Boom XL

Rugged Bluetooth Speaker

IMW270

QUICK START GUIDE

In the Box



IMW270 Baby Boom XL
Rugged Bluetooth Speaker



USB Cable

Carabiner
Clip

A Closer Look



Charging



Powering On/ Bluetooth Pairing



Controlling Music

PRESS	PRESS & HOLD (2 sec)
Volume Up	On/Off
Volume Down	Next Track
Play/Pause	Previous Track



True Wireless Mode Part 1

After connecting Bluetooth with first speaker, power on second speaker.
PRESS & HOLD 2-3 SECONDS

Tap the '⏻' and '+' buttons simultaneously to enter True Wireless Mode on the second speaker.



Tap the '⏻' and '-' buttons simultaneously to enter True Wireless Mode on the first speaker.



Phone Calls/ Just Ask

PRESS	PRESS & HOLD (2 sec)
Answer Call	Reject Incoming Call

End Call





Press x2

To activate JUST ASK and speak to Siri or Google Assistant

Overall battery performance varies dependent upon use, settings and environmental conditions. For further information, please visit www.alteclansing.com

True Wireless Mode Part 2



Once both speakers are in True Wireless mode, they will automatically pair with a Bluetooth enabled device.

With the speakers connected, Stereo Mode uses the speakers as a left and right channel to create a cinematic experience.

est.
FIRST

FOLLOW US ON #myalteclansing